




12" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 2 Doors Each Face
 No Middle Shelf
 PW3612 36" 6




18" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 1 Door Each Face
 1 Adjustable Shelf
 PW2418 24" 5
 2 Doors Each Face,
 1 Adjustable Shelf
 PW2718 27" 5
 PW3018 30" 5
 PW3618 36" 6
 PW4218 42" 7
 PW4818 48" 8




24" & 24 1/2" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 1 Door Each Face
 1 Adjustable Shelf
 PW1824 18" 5 *F/O = 24" High*
 PW2424 24" 7 *S/O = 24 1/2" High*
 2 Doors Each Face,
 1 Adjustable Shelf
 PW2724 27" 8
 PW3024 30" 9
 PW3624 36" 10
 PW4224 42" 10
 PW4824 48" 13



30" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 1 Door Each Face
 2 Adjustable Shelves
 PW1830 18" 5
 PW2430 24" 7
 2 Doors Each Face,
 2 Adjustable Shelves
 PW2730 27" 8
 PW3030 30" 9
 PW3630 36" 10
 PW4230 42" 12
 PW4830 48" 13



36" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 1 Door Each Face
 2 Adjustable Shelves
 PW1836 18" 6
 PW2436 24" 8
 2 Doors Each Face,
 2 Adjustable Shelves
 PW2736 27" 9
 PW3036 30" 10
 PW3636 36" 12
 PW4236 42" 14



42" High, 12" Deep Peninsula Wall Cabinet
 Double Face, 1 Door Each Face
 PW1842 18" 7
 PW2442 24" 10
 2 Doors Each Face
 PW2742 27" 12
 PW3042 30" 12
 PW3342 33" 14
 PW3642 36" 14
 PW4242 42" 16

24" Deep Corner Diagonal Peninsula Wall Upper Cabinets
 See page 22