

Kitchen Peninsula Starter Base Cabinets

34 1/2" High, 20 3/8" Deep

1 Full Height Door


1 Adjustable Shelf, Recessed Toe Kick,

1 Door

BCS2420FD 24" 15

2 Doors

BCS2720FD 27" 16



Kitchen Peninsula Starter Base Cabinets

34 1/2" High, 20 3/8" Deep

1 Full Height Door


1 Adjustable Shelf, Flush Toe,

1 Door

BCS2420FDFT 24" 15

2 Doors

BCS2720FDFT 27" 16



Kitchen Peninsula Base Cabinet,

Double Face, 34 1/2" High

1 Full Depth Adjustable Shelf, Recessed Toe Kick

Front & Back, Front Face: 1 Drawer, 1 Door,

Rear Face: 1 False Front, 1 Door

PB12 12" 8

PB15 15" 10

PB18 18" 11

PB21 21" 13

PB24 24" 15

Front Face: 2 Drawers, 2 Doors,

Rear Face: 2 False Fronts, 2 Doors

PB27 27" 16

PB30 30" 18

PB33 33" 20


PB36 36" 21

PB39 39" 23

PB42 42" 25

PB45 45" 26

PB48 48" 28



Kitchen Peninsula Sink Base Cabinet,

Double Face, 34 1/2" High

Recessed Toe Kick Front & Back

Front Face: 2 False Fronts, 2 Doors,

Rear Face: 2 False Fronts, 2 Doors

PSB30 30" 18

PSB36 33" 21

PSB42 42" 25

PSB45 45" 26

PSB48 48" 28

