

### Universal Single Oven Cabinet, 84" High, 24" Deep

#### 2 Doors above and 3 Drawers below

UOCS2784	27"	38
UOCS3084	30"	42
UOCS3384	33"	45

#### Front Only

##### 84" High, 3" Wide Side Stiles

#### 1 Door Above, 3 Drawer Fronts Below

UOFS2784	27"	5
----------	-----	---

#### 2 Doors Above, 3 Drawer Fronts Below

UOFS3084	30"	7
UOFS3384	33"	7

#### 90" High, 24" Deep

#### 2 Doors Above, 3 Drawers Below

UOCS2790	27"	40
UOCS3090	30"	44
UOCS3390	33"	48

#### Front Only

##### 90" High, 3" Wide Side Stiles

#### 1 Door Above, 3 Drawer Fronts Below

UOFS2790	27"	7
----------	-----	---

#### 2 Doors Above, 3 Drawer Fronts Below

UOFS3090	30"	7
UOFS3390	33"	8

#### 96" High, 24" Deep

#### 2 Doors Above, 3 Drawers Below

UOCS2796	27"	43
UOCS3096	30"	47
UOCS3396	33"	52

#### Front Only


##### 96" High, 3" Wide Side Stiles

#### 1 Door Above, 3 Drawer Fronts Below

UOFS2796	27"	7
----------	-----	---

#### 2 Doors Above, 3 Drawer Fronts Below

UOFS3096	30"	7
UOFS3396	33"	8



### Universal Double Oven Cabinet, 84" High, 24" Deep

#### 2 Doors above and 2 Drawers below

UOCD2784	27"	38
UOCD3084	30"	42
UOCD3384	33"	45

#### Front Only

##### 84" High, 3" Wide Side Stiles

#### 1 Door Above, 2 Drawer Fronts Below

UOFD2784	27"	5
----------	-----	---

#### 2 Doors Above, 2 Drawer Fronts Below

UOFD3084	30"	6
UOFD3384	33"	7

#### 90" High, 24" Deep

#### 2 Doors Above, 2 Drawers Below

UOCD2790	27"	40
UOCD3090	30"	44
UOCD3390	33"	48

#### 96" High, 24" Deep

#### 2 Doors Above, 2 Drawers Below

UOCD2796	27"	43
UOCD3096	30"	47
UOCD3396	33"	52

#### Front Only


##### 96" High, 3" Wide Side Stiles

#### 1 Door Above, 2 Drawer Fronts Below

UOFD2796	27"	7
----------	-----	---

#### 2 Doors Above, 2 Drawer Fronts Below

UOFD3096	30"	7
UOFD3396	33"	8



Cabinet or appliance Installer must trim oven opening(s) to fit oven(s) selected.